



Instruction Sheet For Access Armor Fire Wrap Hold Down Shield

Kit Includes;

(1) pre-notched threaded rod, (1) hold down shield, (1) wing nut, (1) cotter pin

Pre-Installation

Make sure there are no obstructions that will be in the way of the mounting area on the duct such as electric boxes, conduits, brackets, etc.

1) Trim section of fire wrap that is over the Access Armor Duct Access Door to the shape of the access panel. Keep the cut out section.

(1)



2) Attach supplied threaded rods directly to the threaded knobs of the Access Armor Duct Access Doors.

(2)



3) Punch the rods through fire wrap that is trimmed to the shape of the Access Armor Duct Access Door.

(3)

Note: The rods are designed with notches at 1" intervals for trimming, allowing for perfect adjustments for different thicknesses of fire wrap.

4) Secure trimmed fire wrap section in place with the Access Armor Fire Wrap Hold Down Shields

(4)



You will no longer have to re-wrap ducts each time you access the duct for inspection and cleaning.

FOR TECHNICAL ASSISTANCE, CONTACT US AT:

866.704.OMNI • SALES@OMNI-SUPPLY.COM • WWW.OMNI-SUPPLY.COM
1501 COMMERCE DRIVE ELGIN, IL 60123