INSTALL INSTRUCTIONS







SEPA COMPLIANT





Access Armor Repair Kit Instructions



Kit Includes;
I Replacement Gasket
I Tube of Kwik Seal
I Mini Scraper



Step 1

(A) Using provide mini scraper, remove the existing gasket. (B) Make sure to remove any remaining old adhesive.

Step 2

(A) Using the provided sealant/adhesive make a bead all the way around the perimeter of the panel. (B) Cover as much area as possible.

Step 3

Line up the new gasket using the grease seal gasket as a reference.

Step 4

(A) Press the gasket down onto the sealant firmly and evenly. (B) Let the gasket and adhesive set for a minimum of 2 hours before reinstalling the panel to the duct.





