



Instruction Sheet For Roof Guardian Replacement Filters

Roof Guardian Filter Kit Includes:

- (2-4)* Woven Fiber Glass Fire Barriers
- (2-4)* Blue Tuff Pads
- (2-4)* White Insert w/ One Plastic Side
- (2-4)* White Quilted Hydrophobic Filter

Pre-Installation

Install Roof Guardian Roof Bracket first (see other side). If Roof Guardian is already installed, remove metal rods from existing Roof Guardian or Grease Guard. Remove any existing filters and all grease buildup.

1) First place the woven fiberglass high-temperature fire barrier



2) Insert blue tuff pads



3) Insert white inserts with the plastic side face down



4) Insert blue tuff pads



NOTE: All layers of the Roof Guardian need to cover 100% of the area

6) Place metal rods, with existing configuration



*Disclaimer: Due to production and shipping limitation, you may receive anywhere from two to four (2-4) sections of each layer.



FOR TECHNICAL ASSISTANCE, CONTACT US AT:

866.704.OMNI • SALES@OMNI-SUPPLY.COM • WWW.OMNI-SUPPLY.COM
1501 COMMERCE DRIVE ELGIN, IL 60123